

**SMP260**

**Digital Encoder & Transcoder**

**Quick Installation Guide**

# Preface

## About This Document

This document provides introductions and guidelines to users about how to install and operate this equipment quickly.

## Disclaimer





Wellav Technologies Ltd. assumes no responsibility for errors or omissions that may appear in this publication. It reserves the right to change this publication at any time without notice. This document is not to be construed as conferring by implication, estoppel, or otherwise any license or right under any copyright or patent, whether or not the use of any information in this document employs an invention claimed in any existing or later issued patent.

## Intended Readers

- Technical Service Engineer
- Maintenance Engineer
- Test Engineer
- Sales Engineer

## Symbols Definition

For the symbols that might appear in this document, the meanings they represent are as the following:

| Symbol  | Meaning  |
|---|--|
|  | There is highly potential danger. If it cannot be avoided, it will lead to the deaths or serious injury.   |
|  | There is medium or low potential danger. If it cannot be avoided, it will lead to medium or slight injury.   |
|  | There are potential risks. If ignore these texts, it may cause damage to the device, data loss, equipment performance reduce or unpredictable results. |
|  | Tips that help you to solve problems or save your time.  |



Remarks. Additional information to the text, in order to emphasize something.

## Revision History

The revision history lists the modification history. The newest one contains all the modifications of the past revision.

V1.00: First revision. (Date: Nov 26<sup>th</sup>, 2012)

V1.10: Optimize the document structure. (Date: Nov 22<sup>nd</sup>, 2012)

## Contents

|  |    |
|--|----|
| 1. Safety .....  | 5  |
| 2. Check Package and Accessories .....                         | 6  |
| 3. Physical specifications.....                                | 7  |
| 3.1 Physical Specifications .....                              | 7  |
| 3.2 Interfaces and Protocols.....                              | 7  |
| 4. Front Panel and Rear Panel .....                            | 8  |
| 4.1 Front Panel.....   | 8  |
| 4.2 Rear Panel .....   | 9  |
| 5. Installation Instruction .....                              | 11 |
| 5.1 Mounting unit to a 19" rack .....                          | 11 |
| 5.2 Wiring Connection .....                                    | 12 |
| 5.3 Power Connection .....                                     | 13 |
| 6. Operation Instructions .....                                | 14 |
| 6.1 Powering Up & Initializations .....                        | 14 |
| 6.2 Network Connection Setup.....                              | 14 |
| 6.2.1 Navigation Keys Operation Instruction .....              | 14 |
| 6.2.2 Check Out and Change the Default IP Address .....        | 15 |
| 6.2.3 Configuration through NMS.....                           | 15 |
| 6.3 Quick Configuration on Key Parameters .....                | 17 |
| 6.3.1 Check "Status" tab.....                                  | 18 |
| 6.3.2 Configure parameters of signal input modules .....       | 18 |
| 6.3.3 Program IN/OUT configuration in "Program Info" tab ..... | 25 |
| 7. FAQ .....   | 32 |
| 8. Terminology .....   | 33 |

## 1. **Safety**

---

- To avoid electric-shock hazards, do not open the receiver; refer service to qualified personnel only.
- Do not expose the device in the sunlight, and keep it away from the heat source.
- Do not block ventilation holes of the device so that air can circulate freely.
- Switch the device off whenever it remains out of service for an extended period.
- Be sure to turn the device off and disconnect the AC power cord before cleaning the receiver surface.
- The apparatus shall be connected the mains socket outlet with a protective grounded connection
- The appliance coupler used as the disconnect device shall remain operable

## 2. Check Package and Accessories

The SMP260 Encoder package includes the following accessories:

- Base Unit x1
- Power cord x1
- Ground wire x1
- Audio Cable x6
- NMS Installation Disc x1
- BNC Cable x4
- RCA Cable x3
- User guide disc x1

The SMP260 Transcoder package includes the following accessories:

- Base Unit x1
- Power cord x1
- Ground wire x1
- NMS Installation Disc x1
- BNC Cable x1
- User guide disc x1



REMARKS

**Please contact the supplier if it's inconsistent with the actual package.**

### 3. Physical specifications

#### 3.1 Physical Specifications

| Items             | Index               |
|-------------------|---------------------|
| Power             | 90V-260VAC, 50/60Hz |
| Power Consumption | 125W                |
| Size              | 1RU                 |
| Dimension         | 482mm x44mm x 393mm |
| Net Weight        | 5Kg                 |
| Gross Weight      | 7.5Kg               |


#### 3.2 Interfaces and Protocols

| Inputs  | IP input   | ASI input                       |
|---------|--|---------------------------------|
|         | Interface: RJ45  | Interface: BNC, 75Ω             |
|         | Max input bit rate: 1000Mbps                                   | TS package length: 188/204      |
|         | Protocol: UDP/RTP  | Max bit rate: 120 Mbps (per TS) |
|         | Input processing: Up to 12 Sockets, max at 72 Mbps per socket  |                                 |
|         | SDI/CVBS input   | HDMI input                      |
|         | Interface: BNC   | Compatible with HDCP            |
| Outputs | IP output  | ASI output                      |
|         | Interface: RJ45  | Interface: BNC, 75Ω             |
|         | Max input bit rate: 1000Mbps                                   | TS package length: 188          |
|         | Protocol: UDP/RTP  | Max bit rate: 120 Mbps (per TS) |
|         | Input processing: Up to 12 Sockets, max at 72 Mbps per socket. |                                 |

## 4. Front Panel and Rear Panel

### 4.1 Front Panel


#### SMP260-Encoder



Pic-4-1

| Item No. | Functionality   |
|----------|---|
| 1        | Power status indicator  |
| 2        | ASI/IP input status indicator                                   |
| 3        | Input status indicator  |
| 4        | Alarm status indicator  |
| 5        | ASI/IP output status indicator                                  |
| 6        | Encoding status indicator                                       |
| 7        | LED displaying screen   |
| 8        | KEY PADS, including Up/Down/Left/Right arrow keys               |
| 9        | Menu. To enter the menu and the quit function of the sub menus. |
| 10       | OK. To confirm the operation in the setup.                      |
| 11       | ESC. The quit function of the menu.                             |
| 12       | Reset. To reboot the equipment.                                 |

#### SMP260-Transcoder



Pic-4.2


| Item No. | Functionality                 |
|----------|-------------------------------|
| 1        | Power status indicator        |
| 2        | ASI/IP input status indicator |
| 3        | Alarm status indicator        |



|    |   |
|----|---|
| 4  | ASI/IP output status indicator                                  |
| 5  | Transcoding status indicator                                    |
| 6  | LED displaying screen   |
| 7  | KEY PADS, including Up/Down/Left/Right arrow keys               |
| 8  | Menu. To enter the menu and the quit function of the sub menus. |
| 9  | OK. To confirm the operation in the setup.                      |
| 10 | ESC. The quit function of the menu.                             |
| 11 | Reset. To reboot the equipment.                                 |

## 4.2 Rear Panel

### SMP260 Encoder-SDI/CVBS



Pic-4-3


| Item No. | Functionality  |
|----------|--|
| 1        | SDI/CVBS IN (total 6 SDI/CVBS inputs on this model.) |
| 2        | ASI IN   |
| 3        | Balance/Unbalance Audio In                           |
| 4        | ASI OUT  |
| 5        | MANAGEMENT: 100BaseTX,RJ45                           |
| 6        | TS/IP IN/OUT   |
| 7        | POWER  |



REMARKS

There 6 same SDI/CVBS ports and 6 same Balance/Unbalance port in the equipment.

### SMP260 Encoder-HDMI




Pic-4-4

| Item No. | Functionality                                 |
|----------|---|
| 1        | HDMI IN (total 12 HDMI inputs on this model.) |
| 2        | ASI IN  |

|   |                             |
|---|-----------------------------|
| 3 | ASI OUT                     |
| 4 | MANAGEMENT: 100BaseTX, RJ45 |
| 5 | TS/IP IN/OUT                |
| 6 | POWER                       |

### SMP260 Transcoder



**Pic-4-5**

| Item No. | Functionality                |
|----------|------------------------------|
| 1        | Equipped transcoding modules |
| 2        | ASI IN                       |
| 3        | ASI OUT                      |
| 4        | MANAGEMENT: 100BaseTX, RJ45  |
| 5        | TS/IP IN/OUT                 |
| 6        | POWER                        |

## 5. Installation Instruction

### 5.1 Mounting unit to a 19" rack




**ATTENTION** When selecting the installation site, try to comply with the following:

- **Protective Ground** - The protective ground lead of the building's electrical installation should comply with national and local requirements.
- **Environmental Condition** - The installation site should be dry, clean, and ventilated. Do not use this equipment where it could be at risk of contact with water.



**WARNING** To avoid electric shock, make sure the rack has been correctly grounded before switching on the device.



**PIC-5-1**

**PIC-5.1-1 Grounding Jackscrew (must be connected to the rack housing)**


To mount the SMP260 unit to a 19"/42U rack, please perform the following steps:

1. Make sure the mounted rack surface is stable and can support the size and weight of this equipment.
2. For single unit mounting, use an "L" shape slide (not included in the package) to support holding the unit if necessary, and fastened with appropriate screws to each side of the chassis' rails.



**L-shape slide**

3. For group pile up (no space between each unit), the unit should be placed on a flat holding bracket. No more than 5 units for each group, and leave at least one unit space between each group to ensure good air ventilation.




PIC-5-2

## 5.2 Wiring Connection



**1** Before setting up the connection, please turn off the equipment and all other connected external devices. The equipment and all connected external devices are required grounded. Turn on the devices only after the wiring connection is completed. Otherwise the device may be damaged.

Follow the below connection diagram to set up cable connection:



PIC-3

- Set up cable connection for input signal: either the SDI/CVBS input (area 1), ASI input (area 2) or TS/IP input (area 4)

- Set up cable connection for output signal: either through ASI (area 3) or TS/IP (area 4)
- Set up connection for network management control: shown in area 5.



**TIPS** In order to ensure a smooth communication between the management PC and the equipment, please separate the connection of management port and TS/IP output port to different switch. The switch with management port connected should be without large data processing.



**TIPS** The TS/IP port can work for input and output simultaneously. User only needs to connect one RJ45 cable to the TS/IP port of the device.

### 5.3 Power Connection



**ATTENTION** Connect this equipment only to the power sources that are identified on the equipment-rating label normally located close to the power inlet connector(s). Always pull on the plug or the connector to disconnect a cable. Never pull on the cable itself.



**TIPS** To protect your valuable interests and services, equipping a UPS (Uninterrupted Power Supply) and an AVR (Automated Voltage Regulator) to the system is highly recommended.

## 6. Operation Instructions

### 6.1 Powering Up & Initializations




REMARKS

Before powering-up the device, make sure that all cabling is correctly connected (refer to chapter 5.2). The device is correctly connected to the power inlet and grounded.

Switch on the equipment through the back power switch, the unit is powered up and start the initialization.

The LCD screen is lighted up, and display information as following:



SMP260  
Setting subboard1.....

The initialization takes about 20 seconds to complete.



TIPS

If the unit fails to initialize and hangs at the “booting” stage, switching off the device and then powering up again may help. If the device still fails to initialize, please contact your service representative for help.



TIPS

The input/output indicator LEDs turn (red? Off?..) after successful initialization because of signal unlocking. After configuration on the device, corresponding LEDs shall show correct status.

### 6.2 Network Connection Setup

#### 6.2.1 Navigation Keys Operation Instruction



TIPS

Use the 6 navigation keys on front panel: Up / Down / Left / Right / Menu / Ok to enter the configuration menu.

- Enter “Menu”:
  - Press “**MENU**” button to enter main menu.

- **Exit Menu/Back to parent Menu**
  - Upon completion of configuration settings, press “**MENU**” button until you go back to the Parent Menu.
  - You can also go back to Parent Menu directly by pressing “**ESC**” button once.
- **Enter Sub-Menu**
  - Press **MENU** button to enter main menu.
  - Select a sub-menu by pressing arrow **UP** and arrow **DOWN** button.
  - Press **OK** button on the selected sub-menu.
- **To change parameter**
  - Step 1: Enter main menu by pressing **MENU** button.
  - Step 2: Scroll sub-menu by pressing arrow **UP** and arrow **DOWN** button, and press **OK** button to change the selected sub-menu.
  - Step 3: To change parameter settings, press arrow **RIGHT** and arrow **LEFT** button to move the cursor in which change must be made.
  - Press arrow **UP** button and arrow **DOWN** to input / select an appropriate setting, then press **OK** button to save.

### 6.2.2 Check Out and Change the Default IP Address

- Step 1: check out the IP on the LCD screen.
- Step 2: use the button on the front panel to change the IP, gateway and subnet mask.

The gateway should be the same as the management PC's. The subnet mask should be the same as the management PC's s. The IP and the server's IP should be in the same section.
- Step 3: reboot the device to take effect.
- Step 4: ping the new IP on PC to check whether the SMP260 can connect to the management PC.

### 6.2.3 Configuration through NMS




REMARKS

**Accessing the equipment through NMS can be very convenient for remote configuration of the equipment. Relative to the front panel settings, NMS operation can provide a more user-friendly man-machine interface, and less limits in space. For**

quick installation, NMS operation is highly recommended. In this installation guide, operation instruction is based on NMS style. For front panel operation instruction, please refer to product user manual.

- Install the NMS Tool
  - Unpack the accessory CD, and put it on a PC CD/DVD driver;
  - Copy the NMS program on the CD to any folder of the management PC;
  - Use mouse to double click the NMS icon and run the NMS program.



- First Time Log On
  - For first time log on, User Name and Password are required. Default User Name and Password are “**admin**”.



PIC-6-1

- Choose “Remember Me” if user wants to directly log on the NMS without inputting the user name and password.
- Select “Login” to log on the device.



TIPS


Possible reasons for unsuccessful log on:

- IP address/ network mask/gateway don't match with the management PC's
- User name/password is wrong
- Wrong NMS version



- Main Interface Introduction

After successful log on, the following screen will display:



**Pic-6-2**

The interface can be divided into four areas according to its functionality.

- (1) Toolbar. It includes shortcut to change password and save setting etc.
- (2) Equipment list. If more than a piece of equipment is connected to the NMS, the equipment will be listed in this area by its IP address.
- (3) Parameter setting and configuration area. The parameters of the equipment are shown and configured here by selecting different tabs. This is the main operation area of the NMS.
- (4) Event information window.

## 6.3 Quick Configuration on Key Parameters

### 6.3.1 Check “Status” tab

“**Status**” tab: by selecting this item, the NMS displays the current system operation data status of the equipment. User can switch between tab under the “Status” to check the current working status of the equipment

① Different colors of histogram indicate different meaning:

**Orange**: the total input bit rate;

**Blue**: the effective input bit rate;

**Yellow**: the total output bit rate;

**Green**: the effective output bit rate;

**Red**: alarm indicator, it means the actual output bit rate (it's proportional to the amount of the programs you transfer from input port to output port in 'Program Info') is more than the output bit rate of some channel you set in sub-board.

② Communicate Status indicates the communication status between NMS and the equipment.

**Green**: the communication is normal. All the parameters in NMS are updated according to the equipment synchronously.

**Red**: the communication is abnormal. The parameters in NMS may be not updated in time. You need check the network connection and restart the NMS.

### 6.3.2 Configure parameters of signal input modules

■ CVBS/SDI IN

**SD-Encoder\_SD/ CVBS (MPEG-2) module**

The screenshot shows a configuration window for Channel1. The parameters are organized into two columns. The left column includes Video Source (SDI), Audio Source (SDI), Encode Mode (CBR), Video Max Encode Rate (0), Video Min Encode Rate (0), Video Encode Rate (4000), Audio Encode Rate (128K), Encode Rate(Total) (4128), Audio Mode (Stereo), and GOP Struct (IBBFBBFBB). The right column includes Video PID (258), Audio PID (259), PCR PID (260), PMT PID (257), Service ID (1), Transport Stream ID (0), Provider Name (Encoder), Program Name (Program-1), Frame Rate (59.94I), and GOP Size (15). At the bottom, there are buttons for Set, Get, Import, Export, Reboot, Power off, and Factory setting.

Pic-6-3

Following are the key parameters:

| Parameters            | Description  |
|-----------------------|--|
| Channel               | Select a channel to configure its parameters.  |
| Video Source          | To select the correct video source for the input.  |
| Audio Source          | To select the correct audio source for the input.  |
| Encode Mode           | Select CBR or VBR for the encoding mode.   |
| Video Max Encode Rate | To set the Max encode rate for VBR mode. The range of max encode rate is 2000 ~ 15000 Kbps.  |
| Video Min Encode Rate | To set the Min encode rate for VBR mode. The range of min encode rate is 2000 ~ 15000 Kbps.<br><b>Note: the min encode rate must be smaller than the max encode rate.</b>  |
| Video Encode Rate     | To set the encode rate for both VBR mode and VBR mode. The range is 2000 ~ 15000 Kbps. <b>Note: The values of the video encode rate should be between the max encode rate and the mix encode rate in CBR mode.</b> |

|                   |  |
|-------------------|--|
| Audio Encode Rate | To choose the encoding bitrate for the audio.  |
| Encode Rate       | The total encode rate of video and audio contents.<br>Calculated automatically by the software.                        |
| Audio Mode        | To select the audio mode   |
| Frame Rate        | To select correct frame rate according to the input source. The frame rate should be the same as that of input source. |
| GOP Size          | To edit the GOP size   |



REMARKS


(1) There are four different encoder modules: SD-Encoder\_SD/CVBS (MPEG-2), SD-Encoder-CVBS(MPEG-2), HD/SD-Encoder-SD/CVBS(H.264), HD-Encoder-HDMI(H.264).

(2)The input parameters configuration of the four encoder modules are similar.

- ASI IN

### ASI module

There are four ASI port in the equipment. The default setting is: the port 1&2 is for input; the port 3&4 is for output. User can specify the port to be input or output at any time.



Pic-6-4

| Parameters          | Description                              |
|---------------------|--|
| Type                | Set each ASI port to be Input or Output. |
| Packet Size         | Set 188 or 204 packet size for outputs.  |
| Mode                | Set ASI port into CBR or VBR for output. |
| Constant Rate(Mbit) | Set constant bit rate for ASI output.    |
| Max Rate(Mbit)      | Set max bit rate for ASI output.         |
| Min Rate(Mbit)      | Set min bit rate for ASI output.         |

- TS/IP IN

### IP module

Pic-6-5

In the 'System' setting menu, user need to set correct parameters for the IP module such as the IP address, subnet Mask, Gateway, etc, so that the module can work normally in the network.

| Parameters | Description  |
|------------|--|
| IP Address | Set IP address of IP module. The IP address of IP module is used for communication with basic unit of the equipment that |

|              |  |
|--------------|--|
|              | should be in the same IP section with IP address of the equipment.   |
| Subnet Mask  | Set Subnet Mark of the IP module   |
| Gateway      | Set Gateway of the IP module   |
| MAC Address  | MAC address of the IP module   |
| Speed Mode   | Set RJ45 connection speed mode. The speed mode support 100Mbit and 1000Mbit.   |
| IGMP Version | Set IGMP Version for multicast. The IGMP version setting should match the IGMP version of the switch in the network. |

### IP module-Input

The “Input” setting menu is to set the IP input function for receiving multicast/unicast IP stream.

SMP260

Status Program Info System 1:SD-Encoder\_CVBS 2:SD-Encoder\_CVBS 3:SD-Encoder\_CVBS 4:ASI 5:IP (IO) Licenses Upgrade

Input Output Setup

ChannelSelect Channel1 Enable ON

Channel Configuration:

EnableChannel OFF BatchSet

SourceIPAddress 227.40.50.60

SourcePort 1234

Protocol UDP

ColPortMatching Disable

RowPortMatching Disable

IGMPV3SourceAddress 0.0.0.0

FEC Parameter:

ColFECSeen 0

RowFECSeen 0

FECL 0

FECD 0

Bitrate Parameter:

BitrateMode VBR

Set Get

**Pic-3.3-39**

| Parameters                   | Description   |
|------------------------------|---|
| ChannelSelect                | In this 'ChannelSelect', user can select a channel to configure its parameters.   |
| Enable                       | On: enable the IP receiving function.<br>Off: disable the IP receiving function.<br><b>Note: this parameter setting applies to all channels.</b>      |
| <b>Channel configuration</b> |   |
| EnableChannel                | Enable or disable corresponding input channel   |
| SourceIPAddress              | Set the IP address of the multicast/unicast that are going to receive   |
| SourcePort                   | Set port of multicast/unicast   |
| Protocol                     | Select UDP/RTP for multicast/unicast  |
| ColPortMatching              | If the output IP stream quality looks not as good as the input stream, user can select to 'Enable' these two options then to enable the FEC function. |
| RowPortMatching              |   |
| FEC Parameter                | The bigger values it is, the stronger capabilities it has to correct the data mistakes. But the FECL and FECD should be less than 100.                |

- Configure parameters of signal output modules
  - ASI OUT  
The ASI output parament configuraion is introduced in page22.
  - IP OUT

### IP module-Output

The "Output" setting menu is to set the IP output function for transmitting multicast/unicast IP stream.

Pic-3.3-40








| Parameters                   | Description  |
|------------------------------|--|
| ChannelSelect                | In this 'ChannelSelect', user can select a channel to configure its transmitting parameters.   |
| Enable                       | On: enable the IP transmission function.<br>Off: disable the IP transmission function.<br><b>Note: this parameter setting applies to all channels.</b> |
| <b>Channel configuration</b> |  |
| EnableChannel                | Enable or disable corresponding output channel   |
| SourcePort                   | Set port of multicast/unicast  |
| DestIPAddress                | Set IP address of the multicast/unicast.   |
| Protocol                     | Select UDP/RTP for multicast/unicast   |
| EncapNumTSPackets            | Rang 1~7. (Num 7 is recommended)   |
| TSPacketSize                 | Select 188/204 TS packet size  |
| TypeofService                | Select one service type as your requirement. Type including: Normal, Min delay, Monetary cost, Max reliability, Max Throughput.                        |
| <b>Bitrate Parameter</b>     |  |
| Mode                         | Mode includes: CBR/VBR   |




|                    |                                 |
|--------------------|---------------------------------|
| ConstantRate(Mbit) | Set constant bitrate for output |
| MaxRate(Mbit)      | Set max bitrate for output      |
| MainRate(Mbit)     | Set min bitrate for output      |

### 6.3.3 Program IN/OUT configuration in “Program Info” tab

#### Operation Buttons


- a)  Transfer button: to transfer the selected stream/PID from the input program window to the output program window.
- b)  Set button: to apply the changes to the NMS. The setting will lose if the NMS is close or the equipment is powered off.
- c)  To obtain/refresh the current parameters status of the equipment mainboard.
- d)  To save the configuration. The saved data can be kept after NMS is closed or the equipment power off.
- e)  Import a configuration file.
- f)  Export the current settings of the equipment and save as a configuration file.
- g)  To eliminate all the settings in the input and output window.

#### Input program configuration




Pic-3.3-20

① Input Program Configuration: The “Input Program Configuration” is on the left side of the “Program Info” window. It displays all the inserted modules information and the received input streams.





Pic-3.3-21

- a) Board1~4 represents the corresponding slots of the equipment. If the slot is inserted with a card module, the corresponding Board No. will be displayed on the “Input Program Configuration” window, and the name of the inserted module will be displayed after the Board No.
- b) For empty slot, no Board No. will be displayed.
- c) Port No.: represents each physical port of the inserted module.
- d) Scan the input TS: after the parameters of the inserted module are properly configured, select one port which is connected with input stream, and then click the mouse right button and select “Scan TS” menu. All the input stream of that port will be scanned and displayed.



Scan the port that is fed with input stream






Pic-3.3-22


### Output program configuration

Select the port which you want to transmit the output stream.




Pic-3.3-41

- Select a TS stream, click the mouse right button. In the pop-up menu, select “Add TS”.




Pic-3.3-42

- Input the “Original Network ID” and “TS ID” for the channel, and click the “Add” button.



Pic-3.3-43

The input “Original Network ID” and “TS ID” will be assigned to the selected output TS (channel).



Pic-3.3-44


To change the “Original Network ID” and “TS ID”, use the left mouse button to click the TS (channel) name when it is being selected. Then the TS (channel) name will be in editable status.



Pic-3.3-45


To delete the inserted “Original Network ID” and “TS ID”, click the right mouse

button on the TS, and select “Delete”.





Pic-3.3-46

- Select TS which is going to be transmitted on the left hand side “Input Program Info” window, and select the port, TS (channel) which are going to carry the transmission on the right hand side “Output Program Info” window.



Pic-3.3-47

- Click the  button to set transfer of the selected TS from the “Input Program Info” to the “Output Program Info”.



Pic-3.3-48

- Follow above operation steps, user can set the selected input stream to be transmitted at any assigned output TS (channel).

## 7. FAQ

| Problem   | Possible Reasons                        | What to do   |
|---|---|--|
| The LCD display on the front panel does not light up. | No power.                               | Check whether the power cord is plugged into the power socket.                               |
| No Signal output                                      | Parameters are not properly configured. | Check the parameters configuration   |
|   | No signal                               | Check the source and other factors that affect the signal reception.                         |
|   | The cables are not connected            | Check the connection and make sure the connection is well.                                   |
| Cannot have access to the equipment through NMS       | IP setting                              | Check whether the management PC IP and the equipment IP have been set to be in same section. |
|   | Network cable problem                   | Make sure the cable is good one and connect well to the equipment management port.           |



## 8. Terminology

|                     |   |
|---------------------|---|
| <b>A - Z</b>        |   |
| <b>Abbreviation</b> | Specific Meaning  |
| <b>ASI</b>          | Asynchronous Serial Interface                           |
| <b>BNC</b>          | Bayonet Nut Connector                                   |
| <b>CVBS</b>         | Composite Video Broadcast Signal                        |
| <b>DVB</b>          | Digital Video Broadcast                                 |
| <b>EPG</b>          | Electronic Program Guide                                |
| <b>FEC</b>          | Forward Error Correction                                |
| <b>HD</b>           | High Definition   |
| <b>HDMI</b>         | High Definition Multimedia Interface                    |
| <b>ITU</b>          | International Telecommunications Union                  |
| <b>MPEG</b>         | Moving Pictures Experts Group                           |
| <b>PID</b>          | Personal Computer Memory Card International Association |
| <b>RTP</b>          | Real-time Transport Protocol                            |
| <b>SD</b>           | Standard Definition                                     |
| <b>TS</b>           | Transport Stream  |
| <b>UDP</b>          | User Datagram Protocol                                  |



**Digisat International Inc.**  
 4195 W. New Haven Ave., Suite 15  
 Melbourne, FL 32904  
 USA  
 +1-321-676-5250  
 Email: [sales@digisat.org](mailto:sales@digisat.org)  
<http://www.digisat.org>